

beper

- DEUMIDIFICATORE - MANUALE DI ISTRUZIONI
- DEHUMIDIFIER - USE INSTRUCTIONS
- DÉSHUMIDIFICATEUR - MANUEL D'INSTRUCTIONS
- LUFTENTFEUCHTER - BETRIEBSANLEITUNG
- DESHUMIFICADOR - MANUAL DE INSTRUCCIONES



Cod.: 70.420

Important safeguards

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Before using, ensure the voltage of your power supply is the same as that indicated in the instruction manual, only connect appliance to alternating current to a correctly installed earthed socket, cord and plug must be completely dry.

Do not leave the appliance unattended during use.

Do not pull the connection cord over sharp edges; keep the cord away from heat and oil for protection.

Do not place the appliance on hot surfaces or near it.

Do not pull the plug out by the cord or pull it out of the socket with wet hands.

During use children are not allowed to touch the appliance to avoid danger.

If the following happens, please unplug the appliance to disconnect the power supply.

--The appliance or cord has been damaged.

--The appliance is dropped accidentally or any defect is suspected.

Before switching on, ensure the slices of bread do not get jammed in the toaster slots. However, if this happens, unplug the appliance first and then take out the jammed bread slice.

Caution: In the event of burning the bread, the appliance may become too hot. Never touch the toaster at this time.

Note the housing of the toaster will become very hot when using, especially in the area of the toaster slots. Please be careful not to be burned. Please only use the control knob, lever and button for operation.

Do not insert your fingers or metal objects like knives or forks into the bread slots.

Only use the appliance when it is horizontally placed on a suitable surface.

Do not toast the bread with wrapped aluminium foil.

Do not cover the bread slots while in operation.

Never put bread slices or bread roll into the bread slots directly, as this may cause overheating.

Unplug the appliance before cleaning and maintaining.

Do not immerse the appliance into water or other liquid.

Your appliance must never be switched on through an external timer or any kind of separate remote control system. Improper use or repair may cause a risk of danger. In case of misuse or incorrect handling or repair, no liability will be taken for possible damages.

The appliance is only designed for indoors using, not for outdoors using.

Should the cord be damaged, to avoid danger, it should be replaced by the qualified technician of service agency or its authorized service agency.

Do not put the appliance on or near the gas cooker, electro thermal elements or hot plate as well as other electric appliances.

Keep the appliance away from wall, curtain and other combustible material during use.

Don't place anything on the appliance besides baking bread.

Don't use the appliance without bread for a long time.

Use the appliance for domestic purposes only and in the way indicated in these instructions.

Never use the appliance outside and always place it in a dry environment.

Never immerse the appliance in water or any other liquid for any reason whatsoever. Never place it into the dishwasher.

Stand the appliance on a table or flat surface.

The dehumidifier Beper uses Peltier technology (no compressor) which makes it light and quiet. It is perfect for small rooms, Poor ventilation causes musty odour and fungus in wardrobes, larder, etc. The dehumidifier eliminates this problem by keeping them free of unwanted moisture.

Product description

- (1) On/Off button
- (2) 'On' Green LED
- (3) 'Full' Yellow LED
- (4) Air inlet
- (5) Removable water tank
- (6) Dry air outlet
- (7) Lift-slot
- (8) DC power socket
- (9) Rubber feet
- (10) Power supply
- (11) Water displacement hole
- (12) Float switch

To avoid electric shock, do not open, there are no user-Service-able parts inside.



Features

Capacity : Approximately 600ml per day at 30°C, 80% RH

Cooling element : Thermo-electric Peltier module

Water tank capacity : 2Litre

Water level Detector : Automatic switch off with "Yellow" LED
Indicator when water tank is full


Connection

Plug the DC power jack of the switching mode power supply to The DC power socket.

Press the “On/Off” button to “on” position, the Dehumidifier will begin to operate. The green LED will be Turned on. Listen and feel for the air blowing from dry air

Outlet.[as Fig.1] To switch off the unit ,press “On/Off” button to “Off”

Position, the Dehumidifier will be turned off.[as Fig.2]



Removable water tank:

When the water tank is full , with approximately 1.5litre of Water colleted, the unit will be switched off automatically and the “Yellow” LED will be on.

To remove the water tank, first switch off the

Dehumidifier, press”On/Off”button to the “Off” position. Then, remove the water tank from unit and pour the Water out to the toilet or bathroom ,Put the water tank Back into the unit, To continue dehumidifying press the “On/Off” button “On”position again .

Cleaning:

Before cleaning the unit , turn off the Dehumidifier and unplug the plug from the main socket first.

Use a piece of soft cloth to clean the surface of the product

Or use a brush to wipe the dust off the grills of the air Inlet and air outlet.

TECHNICAL DATA

Power: 60W

Power supply: 220-240V ~ 50Hz

For any improvement reasons, Beper reserves the right to modify or improve the product without any notice.



The European directive 2011/65/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain, and reduce the impact on human health and the environment. The crossed out “wheeled bin” symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected.